



Screen Handling and Cleaning

NOTICE: THIS OPTICAL SURFACE SHOULD NOT BE TOUCHED. CONTACT WITH ANY OTHER SURFACE INCLUDING HUMAN CONTACT COULD DAMAGE SCREEN.

UNCRATING AND INSPECTION INSTRUCTIONS:

Upon receipt of crates, open immediately to inspect for concealed damage. In order to avoid damaging your new screen, please take care to stand crate upright, in a manner that will ensure stability. Open side of crate labeled “open this side”. Unscrew cover of crate. Do not use pry bar or hammers to open crate. ALWAYS carry or store screen in upright position. Do not lay flat. **DO NOT TOUCH SURFACE OF SCREEN**. Do not use suction cups on coated surfaces.



Store screen in a cool dry place. Always protect screen from water or excess humidity. Do not expose screen to temperatures in excess of 110⁰ F(37.7⁰ C).

To protect screens, store them in the crate until installation. This will help to prevent accidental scuffing or scratching of optical surface.

CLEANING INSTRUCTIONS:

For dust particles: lightly dust with a soft cotton cloth or blow with canned air (generally used to clean computers). NOTICE: While cleaning, care should be taken to avoid touching the screen with hands.

Surface cleaning: gently wash the screen with a soft cotton cloth and mild solution of dishwashing liquid (2%) and water. Rinse with clean water and dry. When cleaning with soft cotton cloth apply soft pressure so as not to scratch surface.

Never use cleaning agents with solvents, as they may destroy the screen. Never rub hard or persistently on the screen to remove a stain, as this will cause further imperfection.

With proper care your new rear projection screen will give you many years of enjoyment.